

Installing and Connecting Your Airfree Air Purifier

1. Plug power cord into the nearest outlet. Make sure the surface is dry (never place unit on a wet surface) Make sure the side blue led is on.
2. Place Airfree on the floor. Do not install unit under furniture or shelves, or behind curtains as it will reduce air flow and efficiency in reducing microorganisms
3. Airfree P2000 was designed for rooms up to 550 sq. ft. The use of just one Airfree in rooms larger than recommended will reduce its efficiency.
4. Airfree must be continuously on in the same room, 24 hours a day.
5. Airfree can only be used in rooms with minimum air volume of 330 cu. Ft. free of obstacles.
6. Airfree can be installed in rooms equipped with air conditioning and heating systems. However it is recommended not to place Airfree nearby them to avoid potential interference in Airfree flow.
7. Do not place Airfree in the corridor to try to reach the whole house.
8. Do not place Airfree near doors or under windows to avoid sterilized air to exit the room.